



SAFETY INFORMATION: (Please retain for future reference)

- Always make sure the floor lamp is unplugged from a wall socket during assembly'
- This is a Class 2 product and does not require an Earth connection – 230 (240) Volts 50Hz AC..
- Do not cover the light source or lamp shade.
- Do not modify or alter any product before or after installation. This will invalidate your warranty and may render the product un-safe.

POSITION

- This fitting is suitable for installation in indoor locations only, on a flat stable surface .
- Do not place the fitting in a damp atmosphere .
- Ensure sufficient access to the fitting to enable safe maintenance.

LAMP INFORMATION:

- Used LED lamps Only.
- Do not exceed the maximum wattage and bulb type stated on the product.
- This product can be dimmed when using dimmable LED bulbs , using the rotary dimmer switch

AFTERCARE AND MAINTENANCE:

- Always disconnect power supply from the wall socket when servicing or cleaning.
- Clean only with a dry or slightly damp cloth.
- Do not use any abrasive cloths or cleaners as this may damage the product.



This symbol on the product indicates that this must not be disposed of with your other household waste. It is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of wasted electrical and electronic equipment. For more information about where you can drop off your waste equipment for recycling, please contact your local city officer, your household waste disposal service or the shop where you purchased the product.

