



MAINS SUPPLY

LIGHT FITTING



SAFETY INFORMATION: (Please retain for future reference)

- Always turn off the mains supply before commencing the installation of this fitting .
- This is a Class I product and requires an Earth connection – 230 (240) Volts – 50Hz AC.
- This product must be installed in accordance with the National Building Regulations, if in doubt consult a competent electrician.
- Do not cover the light source or lamp shade.
- Do not modify or alter any product before or after installation. This will invalidate your warranty and may render the product un-safe.

POSITION

- This fitting is suitable for installation in indoor locations only.
- Suitable for Ceiling mount only.
- Ensure sufficient access to the fitting to enable safe maintenance.

LED INFORMATION:

- This fitting is suitable for Triac dimming.



- The LED light source cannot be replaced. when the lamps reach the end of their life the whole luminaire shall be replaced



- The control gear can be replaced by a professional.

ADDITIONAL INFORMATION:

- The fitting has a 'rise and fall' mechanism to allow height adjustment. To shorten the fitting hold each wire in turn and gently push upwards to the desire height, the support wire will freely move into the ceiling can. If required the fitting can be lengthened back to the original height, push the small metal release pins in individually, this will release the clamp and allow each support wire to become free to lengthen.

AFTERCARE AND MAINTENANCE:

- Always disconnect power supply when servicing or cleaning.
- Clean only with a dry or slightly damp cloth.
- Do Not use any abrasive cloths or cleaners as this may damage the product.



This symbol on the product indicates that this must not be disposed of with your other household waste. It is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of wasted electrical and electronic equipment. For more information about where you can drop off your waste equipment for recycling, please contact your local city officer, your household waste disposal service or the shop where you purchased the product.

