


McCall's®



Designed and
printed in USA 

M8497



CHILDREN'S, TEENS' AND ADULTS' BUCKET HAT

Suggested Fabrics: Canvas, Cotton Types, Denim, Fleece, Lightweight Sherpa Fleece, Linen Types, Minky Fleece, Twill. **Lining:** Broadcloth, Lining Fabric. **Interfacing:** Lightweight Fusible.

Hat Sizes	XXS	XS	S	M	L	XL	Ins.
Head Sizes	19	20	21	22	23	24	"

Hat

45"*	5/8	5/8	5/8	5/8	3/4	3/4	Yd.
60"**	1/2	1/2	1/2	1/2	1/2	1/2	"

Lining - 45" - 3/8 yd.**

Interfacing

20"	1 1/8	1 1/8	1 1/4	1 1/4	1 1/4	1 1/8	Yds.
-----	-------	-------	-------	-------	-------	-------	------

CHAPEAU BOB POUR ENFANTS, ADOLESCENTS ET ADULTES

Tissus Conseillés: Grosse Toile, Cotonnades, Denim, Molleton, Polaire sherpa légère, Sortes de toile de lin, Minkee, Twill. **Doubleure:** Pipeline fine, Tissu à doubleure. **Entoilage:** thermocollant léger.

Tailles de chapeau	TTP	TP	P	M	G	TG	cm
Tailles de tête	48	51	53	56	58	61	

Chapeau

115cm*	0.6	0.6	0.6	0.6	0.7	0.7	m
150cm*	0.5	0.5	0.5	0.5	0.5	0.5	"

Doubleure - 115cm - 0.3m**

Entoilage

51cm	1.0	1.0	1.1	1.1	1.1	1.3	m
------	-----	-----	-----	-----	-----	-----	---

*with nap **without nap

*avec sens **sans sens


Shop all the pattern brands you love @

Simplicity®.com

M8497



McCall's®
 English
 1-800-782-0323

Page 1 of 2



3 PATTERN PIECES

 1 Crown
 2 Top
 3 Brim

PATTERN MARKINGS

GRAINLINE: Place on straight grain of fabric, parallel to selvage or fold.

FOLDLINE: Place line on fold of fabric.

BUTTONHOLE MARKING: Indicates exact length and placement of buttonholes.

BUTTON MARKING: Indicates button placement.

NOTCHES AND SYMBOLS: For matching seams and construction details.


Indicates the Bustline, Waistline, Hip and/or Biceps. Measurements refer to circumference of Finished Garment (Body Measurement + Wearing Ease + Design Ease). Adjust pattern if necessary. The measurement excludes pleats, tucks, darts and seam allowances.


SEAM ALLOWANCE: 5/8" (1.5cm) included unless otherwise indicated, but not printed on tissue.

ADJUST IF NECESSARY

Lengthen or Shorten at adjustment lines (—) or where indicated on pattern. If substantial length is added, you may need to purchase additional fabric.

TO SHORTEN: Crease along adjustment line. Make a fold half the amount needed. Tape in place.

TO LENGTHEN: Slash between adjustment lines. Spread amount as needed, keeping edges parallel. Tape over paper.


When Alteration lines are not on tissue, lengthen or shorten at lower edge.


CUTTING LAYOUTS
CUTTING AND MARKING

★ Cut other pieces first, allowing enough fabric to cut this piece. Open fabric. For "Cut 1" pieces, cut piece once on single layer of fabric with piece up on right side of fabric.

Pattern may have cutting lines for several sizes. Select the proper cutting line or pattern pieces for your size.

 Before **CUTTING** place all pieces on fabric according to layout. Pin. (Layouts show approximate position of pattern pieces; position may vary according to your pattern size.) Cut **ACCURATELY**, cutting notches outward.


 Before removing pattern, **TRANSFER MARKINGS** and lines of construction to Wrong Side of fabric, using the Pin and Chalk Pencil method or Tracing Paper and Dressmaker Wheel. Markings needed on right side of fabric should be thread traced.

NOTE: Broken-line boxes (a b! c!) in layouts represent pieces cut by measurements provided.




RIGHT SIDE OF PATTERN	WRONG SIDE OF PATTERN	RIGHT SIDE OF FABRIC	WRONG SIDE OF FABRIC
-----------------------	-----------------------	----------------------	----------------------

HAT


USE PIECES 1 2 3

45° (115CM)
WITH NAP
ALL SIZES
INTERFACING

USE PIECES 1 2 3


20° (51CM)
ALL SIZES
SELVAGES

LINING

USE PIECES 1 2

45° (115CM)
WITHOUT NAP
ALL SIZES


SEWING INFORMATION

FABRIC KEY



SEAM ALLOWANCES

Use 1/4" (6mm) seam allowances unless otherwise indicated.



PIN AND FIT

Pin or baste seams, **RIGHT SIDE TOGETHER**, matching notches. Fit garment before stitching major seams.

PRESS

Press seam allowances flat; then open unless otherwise stated. Clip where necessary so they lie flat.

GLOSSARY

Sewing methods in **BOLD TYPE** have Sewing Tutorial Video available. Scan QR CODE to watch videos:

STAYSTITCH - see Machine Stitches: "how to do stay-stitching" video.

TRIM - see How to Sew: Trim, Clip, and Layer Seams" video.

UNDERSTITCH - see Machine Stitches: "how to understitch" video.

SLIPSTITCH - Slide needle through a folded edge, then pick up a 'thread of underneath fabric.

SEWING TUTORIALS




Build your skills viewing short, easy-to-follow videos at simplicity.com/sewingtutorials

PATTERN PIECES WILL BE IDENTIFIED BY NUMBERS THE FIRST TIME THEY ARE USED.


STITCH 1/2" (1.3CM) SEAMS WITH RIGHT SIDES TOGETHER UNLESS OTHERWISE STATED.

HAT


1. Apply INTERFACING to **WRONG** side of hat crown (1), top (2), and brim (3) sections, following manufacturer's directions.




2. Stitch center back seam of crown. Machine-stitch 3/8" (1cm) from raw notched edge.



3. Clip crown to machine-stitching. Pin crown to hat top, matching centers, small, and large dots. Stitch. Lightly press seam toward crown, clipping curves if necessary.



4. Stitch center back seam of hat brim.





5. Stitch center back seam of hat brim facing. Stitch facing to brim along outer edges, matching centers front and seams.


TRIM seam: clip curves.

UNDERSTITCH facing.


TIP: If you intend to turn up brim, take extra care to understitch evenly from finished edge OR omit completely.




6. Turn brim **RIGHT** side out; press. Machine-stitch 3/8" (1cm) from raw edges.




7. On **OUTSIDE**, **TOPSTITCH** brim along all stitching lines OR just along outer stitching line, stitching through all thicknesses.




8. On **OUTSIDE**, pin brim to crown, matching centers front and seams, clipping curves to machine-stitching where necessary. Stitch.




9. Stitch center back seam of crown lining, leaving an opening for turning. Back-stitch at each end of opening to reinforce seam. **STAYSTITCH** upper and lower edges 3/8" (1cm) from raw edge.




10. Clip crown lining to stay-stitching on upper edge. Pin crown lining to top lining, matching centers front and seams; stitch. Lightly press seam toward crown.




11. With **RIGHT** sides together and raw edges even, pin lining to hat along lower edge (over brim), matching centers front and seams. Stitch lower edges together. **TRIM** seam: clip curves.



12. Turn hat through opening in lining; lightly press. **SLIPSTITCH** opening in lining closed.



13. Turn hat **RIGHT** side out.





Congrats!

You've completed your sewing adventure

SHARE YOUR LOOK



Post your pattern and tag us
@simplicity_creative_group and **#simplicitypatterns**
for a chance to be featured on our social media.

Look for more PDF patterns at **simplicity.com**

Have a question or need help with your sewing project call us at
1-800-782-0323

McCall's®
by design group

McCall's® 2024 a division of IG Design Group Americas Inc. • Atlanta, GA 30342 USA www.thedesigngroup.com • All Rights Reserved. www.mccall.com • Made in the U.S.A. Fabriqué aux États-Unis.

To be used for individual private home use only and not for commercial or manufacturing purposes. • A usage privé seulement et non à des fins commerciales ou de production en série. • Para uso privado solamente, no se puede utilizar con propósitos de comercialización o de producción en serie.