


### INSTALLATION:

Please read the information below to help you plan the best location for your movement sensor (PIR) wall light. Once a suitable location has been established, follow the installation instructions..

- The unit must be installed in a vertical position.
- For best results, fix the product to a solid surface, 1.8m –2.5m above the ground.
- Avoid aiming the motion sensor at pools, heating vents, air conditioners or objects which may change temperature rapidly.
- Try to avoid positioning the unit at trees or shrubs, or where the motion of pets may be detected.
- The PIR sensor is more sensitive to movement across the detection area than movement towards it, therefore consider this when planning the position of the wall light.



### ADJUSTING the PIR sensor :

The PIR is adjustable, allowing the detection distance to be changed to suit the location. The detection angle is set at an optimum 90 degrees. The duration the lamp stays on can be altered from approximately 5 seconds to 5 minutes. Use a small screwdriver to gently adjust the 'TIME' and 'SENS' screws. When adjusting the sensitivity (detection distance) in daylight it is necessary to cover the sensor to simulate night time. Alternatively, sensitivity adjustments can be made at night. This is due to a daylight sensor which de-activates the product daylight hours.

Front of sensor	Detection Distance –Adjustable 2-7 metres	Duration bulb on –approx. 5 sec—5mins
<p>90°</p> <p><b>SENS</b> - [Screw icon] +</p> <p><b>TIME</b> - [Screw icon] +</p>	<p>90°</p> <p>3m 5m 7m</p> <p><b>SENS</b> - [Screw icon] +</p>	<p><b>TIME</b> - [Screw icon] +</p>
Adjustment Screws	Detection range can be adjusted by turning 'SENS' screw	Duration the bulb stays on is adjustable by turning 'TIME' screw

### TROUBLESHOOTING:

#### A. Lamp Fails to light:

1. Check mains supply is on
2. Check all electrical connections are correct
3. Check sensor detection distance is correctly adjusted (If applicable).

#### B. Lamp stays on :

1. Check the sensor is not being triggered falsely by moving objects, vehicles, trees etc.



### SAFETY INFORMATION: (Please retain for future reference)

- Always turn off the mains supply before commencing the installation of this fitting .
- This is a Class I product and requires an Earth connection –220 - 240 Volts – 50Hz AC.
- This product must be installed in accordance with the national building regulations, if in doubt consult a competent electrician.
- The Product should not be modified , as this may void the product warranty and render then the product unsafe
- We recommend the use of a suitable RCD, capable of carrying the intended load and which is correctly fused.

### POSITION:

- The fitting is IP44 rated and suitable for installation in outdoor locations. We would recommend the light fitting is installed undercover .
- The fitting is NOT suitable for installation in Marine locations
- The fitting is suitable for fixing onto a flat , solid surface.
- Ensure sufficient access to the fitting to enable safe maintenance.
- The Luminaire should be positioned so that prolonged staring into the luminaire at a distance closer than 0.2m is not expected

### LED INFORMATION:

- This fitting is not suitable for dimming.
- The integrated LED lamps are not replaceable, when the lamps reach the end of their life the whole luminaire shall be replaced.
- The LED chip board & driver are not removable

### AFTERCARE AND MAINTENANCE:

- Always disconnect power supply when servicing or cleaning.
- Clean only with a soft cloth or sponge using warm soapy water and a non abrasive detergent .



## STAINLESS STEEL/ALUMINIUM OUTDOOR LUMINARIES

Stainless steel/aluminium enjoys a strong and enduring reputation for long term appearance and structural integrity. But like all materials they may become stained or discoloured over time, impairing the overall look. This brown discoloration is referred to as “tea staining”. Tea staining can be defined as: Discoloration of the surface of stainless steel/aluminium that does not affect the structural integrity or the longevity of the material.

### CONTRIBUTING FACTORS

The relationships between the contributing factors are complex, but generally become increasingly critical closer to marine environments.

### ENVIRONMENTAL FACTORS

Tea staining occurs most commonly within 5 miles of the sea and becomes progressively worse closer to the marine source. However, wind exposure, pollution levels and higher temperatures can create environments where tea staining may occur outside the 5 mile limit. Therefore we recommend not to place this product within 5 miles of the sea/estuary.

### MAINTENANCE

As with most outdoor products occasional maintenance is required to ensure protection from the elements. We would advise that fine grade oil (Such as ‘Baby Oil’ or WD40) is rubbed into the metal sections of the product. Regular treatment should aid the life and appearance of the product.

### GUARANTEE:

We will not assume responsibility for corrosion or any other resulting damage to our products where they are installed in areas in which fertilizers or salt are present, either in the air or in the soil, or where our products are installed near to chemical plants etc. with emissions of heavily polluted air.