



1

USE AS RECESSED INGROUND



2



USE DRILL WITH $\varnothing 21\text{mm}$
CUT TOOL





3



4



FOR MULTIPLE ASSEMBLY, ALL LED LIGHTS MUST BE CONNECTED IN SERIES
TO A CONSTANT CURRENT 350mA LED DRIVER.



USE AS MOUNTING SLEEVE

USE DRILL WITH $\varnothing 25\text{mm}$
CUT TOOL



2



4

CONNECT TO
350mA LED

3



5

SAFETY INFORMATION: (Please retain for future reference)

- Always turn off the mains supply before commencing the installation of this fitting .
- This is a Class 3 product and does not requires an Earth connection. Do not connect directly to mains supply – 230 (240) Volts – 50Hz AC, must be connected in series to a 350mA constant current LED Driver.
- This product must be installed in accordance with the National Building Regulations, if in doubt consult a competent electrician.
- Do not modify or alter any product before or after installation. This will invalidate your warranty and may render the product un-safe.

POSITION:

- The fitting is suitable for installation in outdoor locations.
- The fitting is NOT suitable for installation in Marine locations.
- The fitting is IP67 rated, we recommend the fitting is not installed where it may become Immersed under water for periods longer than 30 minutes, or depths greater than 1metre.
- The fitting should be installed in areas with adequate drainage.
- Ensure sufficient access to the fitting to enable safe maintenance.

LED INFORMATION:

- This fitting is suitable for dimming when connected to a LED Dimmable Driver.
- The LED lamps are not replaceable, when the lamps reach the end of their life the whole luminaire shall be replaced.

AFTERCARE AND MAINTENANCE:

- Always disconnect power supply when servicing or cleaning.
- Clean only with a dry or slightly damp cloth.
- Do not use any abrasive cloths or cleaners as this may damage the product.



This symbol on the product indicates that this must not be disposed of with your other household waste. It is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of wasted electrical and electronic equipment. For more information about where you can drop off your waste equipment for recycling, please contact your local city officer, your household waste disposal service or the shop where you purchased the product.

